



1 SELECT FOOD




Liquids: soups, cereals, beverages
Semi-solids: oatmeals, mashed potatoes, puddings
Solids: fruits, vegetables, meats

2 PREPARE FOOD




Obi works best when food is prepared within the range above.

3 INSERT FOOD




Fill bowls with food. Overfilling is not recommended.

4 INSERT SWITCHES




Position the device on a stationary, dry, horizontal surface.
Move the Arm to the right, as shown.
Insert the desired Accessibility Switches.

5 INSERT PLATE & PLACEMAT




Clean Plate and Spoon before first use.
Insert the colored Placemat, then place the Plate on top.

6 ATTACH SPOON




Attach the Spoon and press the Power Button.

7 ENTER TEACH MODE



Position the user to be upright and stationary.
Press the Teach Button.


8 DETERMINE LOCATION



If the teach button flashes, the arm is in a non-teachable position and must be repositioned.

Grasp Arm with the thumb covering the Teach Icon. Lift and rotate to position the spoon in front of the user's mouth.
⚠ WARNING: CHOKING HAZARD. Do not teach a delivery position inside of the mouth.

9 EXIT TEACH MODE




Press the Teach Button again to store the position.

Quick Start Guide


EATING

1 CHOOSING FOOD




Touch the Choose Switch to move the Spoon one bowl counter clockwise.

2 DELIVERING FOOD




Touch the Deliver Switch to scoop and transport food to the delivery location.

3 RETURNING ARM




Touch the Deliver Switch to return the Spoon to the bowl.

CLEANING




Clean the Plate, Placemat, and Spoon in a sink or dishwasher (top rack). Clean Obi's Base and Arm with a disinfectant wipe.



If the Power Button flashes, please remove the obstructing object. Once removed, touch either switch and the Arm will resume its motion.

COLLISION

CHARGING



Connect the Charging Cable to Obi's Charge Port and an electrical outlet. All Battery Indicator Lights will illuminate when the device is fully charged.



If you experience an issue with Obi, Email: service@meetObi.com or Call: 1-844-HelpObi.

SERVICE